
Installing Linux OS UBUNTU on Windows 10


Inspired by "How to Run Linux/Bash on Windows 10 Using the Built-In..." by Corey Schafer, YouTube

1. Search on "Features" and select "Turn Windows features on or off". Scroll to bottom of features, select "Windows Subsystem for Linux", and click ok.




Your computer will restart.


2. Goto the Microsoft Store and search on "Linux". Select "Get the apps" button



3. Select the UBUNTU installer and click "Install" button. When complete select "Launch"



- 4. When prompted, type in your username and a password for UBUNTU.
- 5. Open the .bashrc file using nano !!!You can do damage here by accidently changing or deleting text, so only do exactly what is asked in the next step!!!



6. Also realize that you cannot use the mouse to move the cursor in nano, you have to use the arrow keys on the keyboard. **Right clicking** the mouse in nano will **paste** in the location of the cursor, not the mouse.

Copy (ctrl-c) and paste (right click) the following text in the location indicated in the image below to modify the .bashrc file to add a shortcut to your windows home directory, set the DISPLAY so gui apps will run, set the TERM so that nano will work correctly, and run the initialize.bash script fix the domain name bug, then save the changes and exit (ctrl-x).

```
#CEB, add shortcut to windows home directory
export winhome='/mnt/c/Users/cbird/'
#CEB, set display
export DISPLAY=:0
#CEB, set TERM to stop nano cursor misbehavior when ssh to server
export TERM=xterm
#CEB, initialize the /etc/hosts so that I don't have to type in IP addresses
bash initialize.bash
```

```
Select cbird@LAPTOP-URS0LRPO: ~
                                                                                         П
 GNU nano 2.5.3
                                   File: .bashrc
                                                                                    Modified
 ~/.bashrc: executed by bash(1) for non-login shells.
 see /usr/share/doc/bash/examples/startup-files (in the package bash-doc)
 for examples
 If not running interactively, don't do anything
case $- in
    *i*) ;;
      *) return;;
#CEB, add shortcut to windows home directory
export winhome='/mnt/c/Users/cbird/'
CEB, set display
export DISPLAY=:0
‡CEB, set TERM to stop nano cursor misbehavior when ssh to server
export TERM=xterm
CEB, initialize the /etc/hosts so that Idon't have to type in IP addresses
 ash initialize.bash
```

7. Create a script file called initialize.bash in your home directory that will allow you to ssh to domain names rather than just ip addresses

cbird@XPS13-2in1: ~
cbird@XPS13-2in1:~\$ nano initialize.bash

8. Copy (ctrl-c) and paste (right click) the following text into initialize bash then save and close (ctrl-x)

```
#!/bin/bash
#this script initializes my custom settings in UBUNTU on WINDOWS
sudo chmod 777 /etc/hosts
cp ~/hosts /etc
sudo chmod 555 /etc/hosts
```

9. Copy the file /etc/hosts to your home directory with the following command (sudo cp /etc/hosts .). We are going to modify this file to attach a name to the TAMUCC supercomputer's ip address.

```
cbird@LAPTOP-URS0LRPO:~$ sudo cp /etc/hosts .
```

10. Change the permissions on the hosts file by entering the following command

sudo chmod 777 hosts

11. Open the hosts file. Be careful to make only the changes that are asked

```
cbird@LAPTOP-URS0LRPO:~$ nano hosts
```

12. Copy and paste the following line to the hosts file in the location indicated below:

10.20.1.189 hpcm.tamucc.edu

```
# This file is automatically generated by WSL based on the Windows hosts
file:
# %WINDIR%\System32\drivers\etc\hosts. Modifications to this file will b
e overwritten.
127.0.0.1
               localhost
127.0.1.1
             LAPTOP-URSØLRPO.localdomain LAPTOP-URSØLRPO
10.20.1.189
              hpcm.tamucc.edu
72.22.10.254 hobiserver.tamucc.edu
0.0.0.1 mssplus.mcafee.com
# The following lines are desirable for IPv6 capable hosts
       ip6-localhost ip6-loopback
fe00::0 ip6-localnet
ff00::0 ip6-mcastprefix
ff02::1 ip6-allnodes
ff02::2 ip6-allrouters
/etc/hosts (END)
```


13. Change the permissions on the hosts file by entering the following command

sudo chmod 555 hosts


14. Load the new .bashrc settings

```
cbird@XPS13-2in1:~
cbird@XPS13-2in1:~$ source .bashrc
```

15. Update and upgrade UBUNTU. If prompted, enter a "y" for yes. This updates all of the software to the most recent version




16. You need to install xming x server on windows and run it to run gui apps from UBUNTU



17. If you want to run gui programs through ssh within UBUNTU on Windows, then you need to create a ~/.ssh/config file by copying and pasting the following commands into the terminal:

```
mkdir .ssh
nano .ssh/config
```

18. Type the following into the config file, then save and close the file (ctrl x)



19. Lastly, to make nano behave properly on a remote server, open ~/.profile with nano and copy and paste the following function to the end of the file:

```
# This ssh alias function resolves an issue with running nano
within an ssh session
function ssh(){
/usr/bin/ssh -t ${@:1} "stty sane; export TERM=linux; bash"
}
```

```
# This ssh alias function resolves a issue running nano within an ssh session
function ssh(){
   /usr/bin/ssh -t ${@:1} "stty sane; export TERM=linux; bash"
}
```

20. Save and close (ctrl x); you are done!!!